


IMAGE WRITING for Edic-mini Tiny+, Tiny16+. VERSION 1.31

1. Disable antivirus program. Perform all operations as an administrator.
2. Downloaded from our website files should be unzipped into the root of your hard drive in a folder with name containing no symbols.
3. Turn the Recorder to OFF position
 - ✓ for recorders with battery power supply, batteries must be inserted
 - ✓ for recorders with external power supply, power source must be connected.
4. Connect audio recorder to adapter and then adapter to computer.
5. From **Image** folder start **WriteImg.bat**.



```
C:\> D:\WINDOWS\system32\cmd.exe
E:\Output>EMPlusWI.exe /writeimg "EMPlusSetup.exe"
```

6. After the appearance of black window wait for the message "File written successfully: EMPlusSetup.exe" and press Enter.



7. Disconnect the recorder with adapter from PC, then disconnect adapter from the recorder and wait until the led finally turns off.
8. From Start/Programs/EM Plus delete program EM Plus.
9. Connect the recorder to the computer. The PC identifies your Recorder as a removable disk. Open it and start «EMPlus.exe» program. At a first time the program suggests to install software to your PC. Accept it and install the program.
10. After installing the software find the required programs in "Start/Programs/EM Plus"