

Instruction on updating Edic-mini Ray A36 recorder

To upgrade the firmware, follow these instructions:

1. Download Updater 3.41 and unpack it.
2. Connect SPI adapter to the PC, then connect the recorder to the adapter.
3. Press and hold any of three top buttons on the recorder (K1, K2 or K3).
4. Run Updater 3.41 and follow the program's instructions. After program starts operation you can release the button (the program will show the message about it).
5. After update completing run RecManager program and format recorder's memory.

Before start the updating it is recommended to fully charge the rechargeable battery. In case the battery is not fully charged the update process won't be accomplished.

After fulfillment of all updating steps, records in the voice recorder will be deleted. To save all the records download it to the PC before the updating.

If you updated firmware on your recorder always use the latest version of RecManager program.